



Photive Rain Back Panel Replacement

Replace the back panel of your Photive Rain.

Written By: Shozaf Zaidi



INTRODUCTION

Use this guide to remove the back panel of the Photive Rain. Removing the back panel is necessary to access any of the speaker's internal components.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Back Panel



- ❗ Power off the speaker before beginning disassembly.
- Pull the suction cup from its groove in the back of the speaker. Twist and turn the suction cup as needed to remove it.

Step 2



- Remove the four 8.5 mm screws from the back panel of the speaker.
- Remove the back panel.
- ⚠ Pull the back panel away carefully. The battery and speaker are both wired directly to the motherboard.

To reassemble your device, follow these instructions in reverse order.